



- 1
 - (EN) Remove the existing TRV head
 - (DE) Alten Thermostatkopf entfernen
 - (FR) Enlever la tête thermostatique existante
 - (NL) Oude thermostaatknop verwijderen
 - (IT) Smontaggio della vecchia testina termostatica
 - (ES) Retirar el cabezal del termostato antiguo
 - (DA) Fjern det eksisterende følerelement



- 2
 - (EN) Separate the valve base
 - (DE) Ventilaufsatz montieren
 - (FR) Séparer l'embase de la tête
 - (NL) Kraanopzetstuk losnemen
 - (IT) Montaggio dell'attacco della valvola
 - (ES) Separar del termostato de radiador el módulo de acoplamiento de la válvula
 - (DA) Afmonter ventilsokkel




- 3
 - (EN) Select the adapter (optional)
 - (DE) Adapter wählen (optional)
 - (FR) Sélectionner l'adaptateur (facultatif)
 - (NL) Adapter selecteren (optioneel)
 - (IT) Scelta dell'adattatore (opzionale)
 - (ES) Selección del adaptador (opcional)
 - (DA) Vælg adapter (valgfri)

Resideo-Braukmann,
Honeywell,
MNG,
Heimeier,
Oventrop (02/1998),
Siemens

M30 x 1.5




Danfoss RA



Comap/ Hertz
M28 x 1.5




Danfoss RAVL



Danfoss RAV




- 4
 - (EN) Mount the valve base
 - (DE) Ventilaufsatz montieren
 - (FR) Monter l'embase sur l'adaptateur ou le corps
 - (NL) Kraanopzetstuk monteren
 - (IT) Montaggio del regolatore del radiatore
 - (ES) Montaje del termostato de radiador
 - (DA) Monter ventilsokkel




5

- (EN) Inserting & changing batteries
- (DE) Batterien einlegen & wechseln
- (FR) Insérer ou changer les piles
- (NL) Batterijen plaatsen/vervangen
- (IT) Inserimento/sostituzione delle pile
- (ES) Poner/cambiar pilas
- (DA) Indsætning og udskiftning af batterier



6

- (EN) Setting the position of the display
- (DE) Position des Displays einstellen
- (FR) Mettre le support d'écran
- (NL) Stand van het display instellen
- (IT) Regolazione della posizione del display
- (ES) Ajuste de posición de la pantalla
- (DA) Justering af display position



7

- (EN) HR93 binding, see installer guide
- (DE) HR93 verbinden, siehe Installationshandbuch
- (FR) Liaison du HR93, voir le guide d'installation
- (NL) HR93 verbinding, zie installatie instructie
- (IT) Collegamento con HR93, vedi Guida di installazione
- (ES) Vinculando HR93, ver la Guía de Instalación
- (DA) HR93 binding (trådløs forbindelse), se installationsvejledning



- (EN) Download full instruction guide on :
- (DE) Download der Bedienungsanleitung unter:
- (FR) Télécharger la notice détaillée sur :
- (NL) Download volledige installatie instructie op:
- (IT) Scarica le istruzioni complete da:
- (ES) Descargar manual de instrucciones en:
- (DA) Download komplet instruktionsvejledning på:

www.resideo.com

